



DEVICE DESCRIPTION

LABEL	DEVICE APPLICATION
FSR	FAN START RELAY
FCR	FAN CONTROL RELAY
SR1-11	NORMAL OPERATION RELAY
HSR	HORN SILENCE RELAY
CLR1-4	CONTROL LOCATION RELAY
LDR	LOAD DUMP RELAY
NOR	NORMAL OPERATION RELAY
AHR	ALARM HORN RELAY
S2-S16	CONTROL SWITCH